



## Spareparts




**SCHROEVENDRAAIER 1/4" PISTOOL**

**TOURNEVIS 1/4" PISTOLET**

**CE**

**Bestelnr./N° de cde. 29032**

## 29032 / A15-766 1/4" Screwdriver (External Adjustable Clutch)



Index No.	Part No.	Description	Q'ty	Index No.	Part No.	Description	Q'ty
1	766-022	Torque Adjuster	1	31	00-2331	Ball Bearing	1
2	757-026	Anvil Collar	3	32	757-005	Front End Plate	1
3	757-025	Holder Spacer	1	33	00-3325	Spring Pin	3
4	757-027	Spring	1	34	766-006	Rotor	1
5	757-024	Quick Change Holder	1	35	757-008	Rotor Blade	6
6	757-023	Washer	1	36	757-006	Cylinder	1
7	766-019	Adjusting Screw	1	37	757-009	Rear End Plate	1
8	766-021	Snap Ring	1	38	00-2332	Ball Bearing	1
9	766-004	Thread Fixer	1	39	767-019	Reverse Valve	1
10	766-020	Bushing	1	40	767-020	Spring	1
11	766-003	Front Housing	1	41	00-4118	O-Ring	1
12	766-005	Ring	1	42	766-001	Motor Housing	1
13	00-4603	Grease Fitting	1	43	301-034	Spring	1
14	766-017	Washer	1	44	00-3805	Steel Ball	1
15	00-3813	Steel Ball	18	45	767-021	Reverse Valve Knob	1
16	766-015	Washer	1	46	00-3304	Spring Pin	1
17	766-016	Spring	1	47	00-3319	Spring Pin	1
18	766-014	Washer	1	48	306-025	Trigger	1
19	766-011CH	Anvil	1	49	00-3326	Spring Pin	1
20	00-3811	Steel Ball	4	50	305C-022	Bushing	1
21	766-010	Clutch Plate	1	51	305C-021	Valve Stem	1
22	766-002	Housing Cover	1	52	767-028	Spring	1
23	00-2306	Ball Bearing	1	53	767-026	Exhaust Deflector	1
24	766-018	Washer	1	54	767-023A	Air Inlet (1/4" PF)	1
25	00-3819	Steel Ball	1	54	767-023B	Air Inlet (1/4" PT)	
26	766-009	Gear Housing	1	54	767-023C	Air Inlet (1/4" NPT)	
27	00-3415	Pin	3	55	767-027	Muffler	1
28	216-017	Idler Gear	3	56	00-3342	Spring Pin	1
29	766-008	Idler Gear Housing	1	57	767-022	Hanger	1
30	766-007	Spacer	1	58	766-024	Wrench	1

Remark : Please do use the correct bit as recommended size in order to extend the life of tool.

